

**2016+ R NINE T SCRAMBLER WS-668F
FRONT SEAT INSTALLATION INSTRUCTIONS**

Tools Required: T25 L-Key (provided)
T30 L-Key (provided)

Preparation:

1. Remove your one piece seat.
2. Remove the factory installed seat mounting bracket from bike. **Fig A**



Installation: Your new Sargent front seat installs in a similar fashion as the OEM. Place the Sargent seat's front and middle "catches" on the bike behind the frame "catches," then slide the seat forward with slight downward pressure to engage. Ensure that all catch points are engaged. **Failure to do so can damage the seat.** Install the provided bolts to secure the seat. Install the rear component of your choice.

