
DDC-100

Installation Guide





Safety Matters



Note:

Please be noted the device can tell (alarm) Fatigue or Distraction ONLY, rather than the exact behavior itself. The events shown just mean they are under F or D category.

Output Data

				DDC-100
NO	ITEM	ОИТРИТ		GPIO
1	function	1.1	fatigue	yes
		1.2	distraction	yes
2	configuration	2.1	add alarm (preset)	-
		2.2	*alarm sound (on/off)	yes
		2.3	volume adjustable	-
		2.4	installation position	yes
		2.5	vibration (with Bands)	-
		2.6	sensitivity	yes
3	status report	3.1	green (LED)	yes
		3.2	yellow (LED)	yes
		3.3	red light (LED)	yes


Getting Started

- 1. Android Phone ONLY (Download here: smartwitness.com/software/DDC100.apk)
- 2. App downloaded & installed
- 3. Power on the device
- 4. Pair with the device












Installation Options










- 1. Click the Start: a black face outline is displayed
- 2. Make the device facing straight to your face after seated (as driving state)
- 3. Fine tuning the device by moving
 - far/close
 - up/down, or
 - left/right

till the black face outline overlapping with this blue line (as shown left chart)

- 4. Mount/screw tight the device at this location
- 5. The calibration is done

More Settings



Alarm:

- On/Off at all driving speed
- Off at low speed (<20kmh)

Alarm Sensitivity:

- Low: F @ >=2.1s, D @ >=4.0s

- Normal: F @ >= 1.5s, D @ >= 3.0s

- High: F @ >= 1.2s, D @ >= 2.0s

- F = Fatigue
- D = Distraction

WARNING

DDC-100 can be annoying...

if you are NOT driving safely!













